

IBM

Correcting Selectric® III and
Selectric® III Typewriters
Operating Instructions



Refer to this photograph to help you locate the individual features of your IBM Correcting "Selectric" III Typewriter and IBM "Selectric" III Typewriter.



Features

With the IBM Correcting Selectric® III Typewriter, erasures, strikeouts, and messy corrections can be a thing of the past. The IBM High Yield Correctable Film Ribbon and IBM Lift-off Tape system allows you to lift incorrectly typed characters off the page. The IBM Correcting "Selectric" III Typewriter also allows you to use the IBM Tech II Ribbon with the IBM Tech III Cover-Up Tape for certain applications.

In addition, both the IBM Correcting "Selectric" III Typewriter and the IBM "Selectric" III Typewriter utilize single-element typing technology.

The following features are available on the IBM Correcting "Selectric" III or "Selectric" III Typewriters:

Interchangeable Typing Elements:

A choice of over 20 available for every typing need.

Page-End Indicator: As you type down the page, the indicator tells you the amount of space remaining on the paper.

Larger Keybuttons: The keys have been enlarged 25%.

Optional Acoustical Hood: The perfect choice in sound-sensitive working areas.

Express Backspace Key: A major convenience factor when underlining or rapidly backspacing.

Impression Control: Easy to use and adjust to suit each typing application.

The following features are available on the IBM Correcting "Selectric" III Typewriter only:

Dual Pitch: Choose a 10-pitch or 12-pitch type style to suit each application.

Lighted Margin Scale (not applicable to all models): The 10- or 12-pitch scale lights according to the pitch selected.

Half Backspace Lever (dual-pitch models only): Ideal for creating ligatures or correcting already typed copy.

The following instructions and illustrations provide a quick, convenient way to help you realize the full benefits of your new IBM typewriter.

Preparation



On/Off Control

To turn the typewriter on, depress the top part of the On/Off control.

Warning: Keep hair, fingers, and personal objects (such as bracelets, neckties, neckties, and so on) out of the printing and ribbon area when the machine is on.

In order to prevent long hair, fingers, and personal articles from getting caught on the rotating shaft in the machine, you should comply with this warning, you should ensure that other persons do also.



To Change Element

Use an element with a ▲ when typing in 10 pitch and an △ when typing in 12 pitch.

Only elements with yellow labeling on the top may be used on this typewriter.

To put on an element:

- Tap the shift key to be sure it is not locked.
- Open the lever on top of the element until it is all the way open, as shown above.
- Hold the element by the lever and place it on the element post, pointing the yellow triangle toward the post.
- Close the lever all the way down.



To remove an element

- Tap the shift key to be sure it is not locked.
- Lift the lever on top of the element until it is all the way open, as shown above.
- Use the lever to lift the element straight up off the element post.



Margin Pitch Scale

(Single-Pitch Model)

This scale is located directly above the keyboard. The 10 or 12 at the left of the scale indicates the typewriter's pitch.

The scale is numbered every five spaces from left to right.

A white pointer moves along the scale with the carrier, indicating the typing position of the next character to print.

On top of the element is a 10 ▲ or 12 △ indicating the pitch. Use an element with a 10 for a 10-pitch typewriter; use 12 for a 12-pitch typewriter.



Pitch Selection Lever

(Dual-Pitch Model)

If your typewriter is a Dual-pitch model, it is designed to allow typing in either 10 or 12 pitch.

Move the pitch selection lever toward you for 12-pitch typing and away from you to type in 10 pitch.

10 pitch (Fits)
10 characters per inch

12 pitch (Fits)
12 characters per inch



Margin Dual-Pitch Scale

(Dual-Pitch Model)

Some dual-pitch models have a lighted margin scale. For your convenience, only the scale corresponding to the pitch in use will light.

- Moving the pitch selection lever switches the illumination from one scale to the other.

A red pointer moves along the scale with the carrier, indicating the typing position of the next character to print.

Use an element with a 10 ▲ when typing in 10 pitch; use a 12 △ for 12 pitch.

Note: Using a typing element of one pitch when the typewriter is set for the other pitch will alter only the amount of space between characters.



Feeding Paper

Align the paper against the paper edge guide.

Pull the paper ball lever forward.

Depress the index key to roll the paper into the typewriter.



Paper Release

To remove the paper or to reposition the paper after it is inserted in the typewriter, pull the paper release lever forward.

- * Use this feature when inserting a thick carbon pack.

Push this lever back after the paper has been removed or is in the desired position.



Impression Control

The impression control adjusts the striking force of the element. For most jobs, set the control on three.

- * Move the control to the right before changing the position.

For greater striking force, move the control to a higher number (example, multiple carbon packs, stencils.)

For less striking force, move the control to a lower number (example, offset masters).



To Set Margins

Push in and slide the margin stops to the new margin setting.

The left margin stop cannot be moved to the right beyond the pointer. Use the scoopbar to move the pointer out of the way before moving the margin stop.

- You can also use the margin release key (page 5).

The right margin stop prevents you from typing past the right margin; however, you can space or tab through it. To type past the right margin, depress the margin release key (page 5) and continue typing.

Note: On dual-pitch models, there is a white indicator to show where the left margin stop is.



Use Space Lever

Move the line space lever toward you for single spacing, to the middle mark for space-and-a-half spacing, and away from you for double spacing.

- Your typewriter may have single and double spacing. You may want to check the spacing in your typewriter.



Margin Release

To temporarily release the left margin, return the carrier to the left margin, depress the margin release key, and backspace through the margin.

To type through the right margin after the keyboard locks, depress the margin release key and continue typing.



To Set and Clear Tabs

Use the tab control to set and clear tabs. To set a tab, move the carrier to the space where you want to set a tab and depress Set.

To clear a tab, tab to the stop you want to clear and depress Cl.

To clear all tabs at once, tab the carrier all the way to the right, hold down Cl as you depress the carrier return or the express backspace key.

(Dual Pitch Model)

If a document will contain both pica and elite, set your tabs at a numbered marking on the 10-pitch margin scale.

The pointer should be at least two spaces before a tab stop in order to tab to that position.

Note:

A partial carrier return can be used to type tabulated material, such as columns of figures or addresses on envelopes.

Set tab stops first. Then tap the carrier return followed by the tab key as soon as the carrier passes the tab stop.

Typing forms is faster when you set tab stops at the points on the form where most of the typing begins. Use the partial carrier return to go directly to a predetermined point on the page; that is, tap the carrier return followed by the tab key as soon as the carrier passes the tab stop.



Express Backspace Key

Use the express backspace key (Exp) to move backward on the same typing line for underlining or repositioning the carrier. The carrier will continue to move back toward the left margin as long as the key is held down.



Shift Keys and Shift Lock

To type capital and other upper case characters, depress either the left or right Shift key.

To lock the shift key for continuous use, depress Lock.

To unlock the shift key, depress the left or right Shift key.

Checklist for Proper Typewriter Operation

- If typewriter does not turn on, be sure the electric cord is plugged into the outlet.
 - The On portion of the On/Off should be depressed.
- If nothing prints on the paper, make certain the ribbon/ceramic control (page 10) is not in the stencil position.
- If the carriage will not move, turn the typewriter off for a few seconds. Then on. Depress the margin release key or tab key to release the carrier.
- If erratic line spacing occurs, check to see that the line finder (page 12) is not forward.
- If the ribbon is not printing properly, make sure that the ribbon (page 13) and the correcting tape (page 14) have been installed correctly.
 - On a fabric ribbon typewriter, reverse the ribbon manually (page 10) and continue typing (page 10).
- If characters are crowded or too far apart, check to see if the pitch selection lever matches the element.
- If an element has been dropped or erratic character spacing occurs, check the bottom of the element for a broken tooth. If a tooth is broken, the element will have to be replaced.



Page-End Indicator

The page-end indicator will

- Show you approximately how far you are from the bottom of a page.
- Support the paper for easy viewing.




For paper inserted vertically:

Use the top three lines of the indicator for paper inserted vertically.



For paper inserted horizontally:

Use the lower three lines of the indicator for paper inserted horizontally.



To Center Information

Horizontally

- Move the carriage to the center of the paper.
- Backspace once for every two characters to be centered.
- Type the information.

Vertically

Normal typewriter spacing provides six vertical lines per inch of 95 lines per standard page, 11 inches (279.60 mm) long.

- Use the page-end indicator (page 7) to gauge the bottom margin.



To Center the Paper

To center any width paper, insert the paper so that its left and right edges touch the same number on the paper centering scale. For example, for paper 8 1/2 inches (215.90 mm) wide, both edges touch 4.


- When paper is centered in the typewriter, the dot in the center of the margin scale is the center of the page. See illustration above.

When paper is inserted so that the left edge is aligned with zero on the margin scale, use the first dot for the center of paper 8 1/2 inches (215.90 mm) wide.

As You Type



To Make a Correction

- Depress the correcting key  to backspace to the last incorrectly typed character.
 - The correcting key is typematic repeat action, so you can quickly backspace to correct any character toward the beginning of the line.
- Reshake the last incorrectly typed character to delete it from the paper.
- Backspace with the correcting key to the next incorrect character and reshake it to delete it from the paper. Repeat until all incorrect characters are deleted.
- Type the correct character(s).

If you are typing carbon copies, correct them in the usual way after deleting the character(s) from the original.

If you space after backspacing with the correcting key, the correcting process is released.

Use either IBM High Yield Correctable Form Ribbon with IBM Lin-off Tape or IBM Tach or Ribbon with IBM Cover-up Tape. If it is necessary to match the appropriate tape and ribbon. For your convenience, they are color coded.

1. When typing offset readers do not use:
- The IBM High Yield Correctable Form Ribbon, or
 - The correcting key when using the IBM Tach or Ribbon.



To Type Stencils

Ribbon Cassette System and Selective Ribbon System

Ribbon Cassette System: Push the ribbon/wrench control to the left so the "S" lines up under the mark.

Selective Ribbon System: Push the ribbon/wrench control in and to the left so the "S" lines up under the mark.

To return to regular typing (for either system), push the button on the control. This automatically moves the control to printing position.

Fabric Ribbon System

To type stencils, move the ribbon/wrench control to position "0."



Fabric Ribbon Typewriter

For regular typing, set the control on "1," "2," or "3" to type on the top, middle, or bottom portion of the ribbon. Change the position frequently to allow the ribbon to re-wick itself for longer life.



Typematic Keys

Typematic keys have both a single and repeat action. Any of the typematic keys can be touched lightly for single action or depressed and held all the way down for repeat action.

- Backspace
- Spacebar
- Hyphen/Underscore
- Index
- Correcting key (available on the IBM Correcting "Selectric"® II Typewriter only)
- Corner Return

* Index key is used to space down the page without the carriage returning to the left margin.



Cardholder

The cardholder holds paper, cards, and envelopes close to the platen.

- The red vertical line at the top center of the cardholder indicates the position of the next character to be typed.

To re-align characters for a correction, use the markings on the cardholder as a guide. First, position the characters in the small vertical lines at the top of the cardholder. Then, roll the paper down to the horizontal line at the bottom of the cardholder. This line indicates the base of the typing line. Position your paper so the bottom of each character rests just above the line, as illustrated above.

The red vertical line on the cardholder can also be used to re-align characters.

Position an "I" or an "l" directly under the vertical line at the top of the cardholder. Then, roll the paper down to the horizontal line at the bottom of the cardholder. This line indicates the base of the typing line. Position your paper so the bottom of each character rests just above the line.



To Draw Lines

You may use the notches of the cardholder to draw vertical lines.

Push the slip feeder lever (page 12) forward so you can roll the platen freely.

Remember to return the lever to its original position for normal line spacing.



Line Finder

The line finder allows you to temporarily leave the original typing line to type a superscript, subscript, double underline, a form with irregular spacing, or to draw lines.

- Pull the line finder lever toward you.
- Turn the platen knob to move to the temporary typing line and type.
- To return to the original typing line, push the lever away from you. Then roll the platen to the original typing line.



Half Backspace Lever

(Dual-Pitch Model Only)
Use this lever to spread or squeeze characters or create a ligature (example, *ll*).

- Pull the half backspace lever forward and hold.
 - Carrier moves back one-half space.
- Type the character(s).
- Release the half backspace lever.
 - Carrier moves forward to its normal typing position.

Note: Typing with the lever forward allows regular character spacing, but one-half space out of the normal typing position.



Platen Variable

Press in the left platen knob to permanently change the position of the writing line or to reassign a page for correction or additions.

Care of the Typewriter



Ribbon Systems

Following are instructions on how to remove and install ribbons from the Ribbon Cassette, Selective Ribbon, and Fabric Ribbon Systems. Choose the ribbon system instructions that correspond to the ribbon system on your typewriter.

To avoid any confusion in matching ribbon cartridges with the corresponding connecting tape for the IBM Connecting "Selectric" III Typewriter, ribbon cartridges and tapes are color coded.

See "Ordering Procedures" on page 22 to order ribbons and other supplies.



Ribbon Cassette System

To see how much ribbon remains in the cassette, look at the ribbon-end indicator (A).


To remove a ribbon:

- Press the spacebar to move the carrier to the center.
- Switch the typewriter off.
- Lift the cover.
- Keep the paper ball against the plate.
- Move the ribbon load lever (B) to the load position (1).
- Using both hands, lift the cassette straight up and off.

To install a ribbon:

- Be sure the ribbon load lever (B) is in the load position (1).
- Using both hands, place the cassette over the two posts.
- Push down firmly on the cassette.
- Turn the knob on the cassette in the direction of the arrow until the unlinked part of the ribbon disappears inside the cassette. If the ribbon is not tight, turn the knob on the cassette in the direction of the arrows.
- Move the ribbon load lever (B) back to the operating position (2).
- Close the cover.

¹ The ribbon load lever on your typewriter cannot be moved if the connecting tape load lever (C) is in the load position.



Selective Ribbon System

To see how much ribbon remains in the cartridge, look at the ribbon-end indicator (G).


To remove a ribbon:

- Press the separator to move the carrier to the center and switch the typewriter off.
- Lift the cover.
 - If your typewriter has an automatic hood, pull it toward you before lifting the cover.
- Keep the paper ball against the platen.
- Move the ribbon load lever (A) to the load position (T) until it clicks against the stop (F).*
- Using both hands, hold the ribbon cartridge at the front corners (H) and lift the cartridge straight up.

To install a ribbon:

- Be sure the ribbon load lever (A) is in the load position (T).
- Put the ribbon leader (unreel portion) on the outside of the guidepost (B) and ribbon guides (C) and (D). Feature 20 50 50 will cause ribbon breakage.
- Position the ribbon cartridge so that it fits between the spring clips (E). Firmly push down on both ends of the cartridge.
- Thread the leader through the ribbon guides (C) and (D).
- Turn the knob on the cartridge in the direction of the arrow until the leader disappears inside the cartridge.
- Move the ribbon load lever (A) to the type position (Z).
- Close the cover.

* The ribbon load lever on the IBM Correcting "Selectric" II Typewriter cannot be moved if the ribbon lever (A) is in the load position.



Fabric Ribbon System

To remove a fabric ribbon:

- Center the carriage, then, turn the motor off.
- Lift the cover.
 - If your typewriter has an anatomical hood, pull it forward you before lifting the cover.
- Keep the paper flat against the platen.
- Move the ribbon change lever (A) to the far right to raise ribbon guides (B) and (C).
- Lift the cartridge upward and off the spindles (D) and (E).
- Ease the ribbon out of the ribbon guides (B) and (C).


To install a fabric ribbon:

- The carriage should remain centered and the motor off.
- Keep the paper flat against the platen.
- Be sure that the ribbon change lever (A) is at the far right.
- Position the cartridge in front of the ribbon guides (B) and (C) and thread the ribbon through these guides.
- Place the cartridge on the spindles (D) and (E) and press down.
- Move the ribbon change lever (A) into the typing position.
- To take up the slack in the ribbon, turn either spindle (D) or (E) in the direction of the arrows.

Ribbon Reverse Lever

(Fabric Ribbon Model Only)

Fabric ribbons reverse automatically when either side of the cartridge becomes empty. However, to manually reverse the ribbon, press the ribbon reverse lever nearest you to the rear.



Changing the Carriage Paper

To remove the tape:

- Move the tape load lever (J) to the right.¹
- To lift off the empty tape spool (M), twist slightly clockwise, remove take-up spool.

To install new tape:

Remember: Use an orange spool with a ribbon which has an orange knob; use a blue spool with a ribbon which has a blue knob.

- Gently separate the two spools, but keep them connected by the orange or blue tape (leader).
- Place new tape spool (K) on the left spindle.
- Thread the leader through the guide (L), behind the separator wire (M), and behind the guide (N).
- Place the take-up spool (O) on the right spindle. Turn the take-up spool in the direction of the arrow until the leader is past the guide.
- Move the tape load lever (J) to the left. (The lever must be closed before you begin to type.)

¹ The tape load lever cannot be moved if the ribbon load lever is in the load position.



Serial Number

To locate the serial number:

- Tab the carriage all the way to the right.
- Raise the typewriter cover.
- Locate the number directly below the platen toward the left on the metal bar as shown in the illustration.

Cleaning the Typewriter Cover or Spools Head

Use only a mild detergent to clean the plastic parts and painted portions of the typewriter. Certain cleaning fluids may be harmful. Where stubborn stains persist, consult your service person.

Cleaning the Type Element

Remove the element from the typewriter and clean it with a dry brush and cloth.

Note: The element will break if you drop it on a hard surface.

Closing the Dust Cover

Cover the typewriter at the end of each day. The dust cover protects the typewriter from scratches and keeps out dust and other foreign matter.

Typewriter Maintenance and Service

To maintain efficient operation, your typewriter should receive periodic inspection and lubrication by trained service personnel only.

When You Call for Service

If your typewriter needs to be repaired, make a note of the problem when you call for service. If possible, save a sample of the problem. The sample will help the service person diagnose the problem and repair the typewriter.

IBM Supplies



Note: The name and reorder number of each ribbon appear on the underside of the ribbon cartridge.

IBM 210 Correctable Ribbon Cassette

IBM Color Correctable Ribbon Cassette

Equipment: IBM Correcting Selectric II Typewriter

Average Annual Usage: 9-12 ribbons¹

Shell Life: Three years

Colors: Black, Brown, Green, Blue

Average Character Yield: 288,000²

Packaging: One ribbon per box (minimum order - one dozen boxes)

Reorder Numbers:

Black: 1299506

Brown: 1299510

Green: 1299511

Blue: 1299512

IBM Lift-off Tape works with the IBM 210 Correctable Ribbon Cassette and the IBM Color Correctable Ribbon Cassette. It lifts incorrectly typed characters off the page.

Reorder Number: IBM Lift-off Tape: 1136432



IBM 500 T-ii Ribbon Cassette

Equipment: IBM Correcting Selectric II Typewriter

Average Annual Usage: 2-4 ribbons

Shell Life: Two years

Color: Black

Average Character Yield: 800,000

Packaging: One ribbon per box

(minimum order - two boxes)

Reorder Number: 1299509

IBM Tech II Cover-up Tape works with the IBM 500 T-ii Ribbon Cassette. It covers up incorrectly typed characters.

Reorder Number: IBM Cover-up Tape: 1136425

¹ Colors other than black have an average character yield of 180,000.

² Colors other than black have an average annual usage of 12-15 ribbons.



IBM High Yield Correctable Film Ribbon

Ideal for typing original documents. Designed specifically for air-respondered typing. Best results are obtained with less than three carbon copies. Carbon copy sheets should be lightweight, smooth surfaced paper. Carbon paper weight should not exceed 6 lbs. (22.5 grams) in weight. The first or original sheet should be a good 16-20 lb. (60-75 grams) bond paper.

Since the receptivity of the surface of these papers varies, it is best to first try the ribbon on the paper to be used. It is not recommended for OCR, Direct Image Offset Masters, Photo-Master Paper, or Negatable Instructions. Type styles larger than Courier will not achieve maximum results. This ribbon is not recommended for use with Oxiart type style. For these applications the IBM Tech 10 ribbon should be used.

Equipment: IBM Correcting "Selective" II Typewriter with the selective ribbon system

Average Annual Usage: 12-16 ribbons

Shelf Life: Three years

Colors: Black, Blue, Green, Brown

Average Character Yield: 150,000

Packaging: 9 ribbons per box (Minimum order - 2 boxes)

Reorder Numbers:

Black: 1292925

Blue: 1292941

Green: 1292952

Brown: 1292962



IBM L-Ribb Tape

Works in tandem with IBM High Yield Correctable Film Ribbon to lift incorrectly typed characters off the page. Some thin papers such as small papers are not recommended. Try the tape on the paper first.

Equipment: IBM Correcting "Selective" II Typewriter

Average Annual Usage: 12-16 ribbons

Shelf Life: Two years

Color: White

Average Character Yield:

Approximately 2,000 corrections

Packaging: 3 tapes per box (Minimum order - 1 box)

Reorder Number: 1136433



IBM Tech III Ribbon

Ideal for all general-purpose typing, offset masters, hard-to-image surfaces, and some OCR applications.

Equipment: IBM "Selectric" III Typewriter (with or without correction capability) equipped with the selective ribbon system.

Average Annual Usage: 3-6 ribbons

Shelf Life: Two years

Average Character Yield: 580,000

Color: Black

Packaging: 1 ribbon per box (Minimum order - 1 box)

Reorder Number: 1126391



IBM Tech III Correcting Tape

Developed to work in combination with IBM Tech III Ribbon to cover up incorrectly typed characters. Not recommended for Direct Image Offset Masters.

Equipment: IBM Correcting "Selectric" III Typewriter

Average Annual Usage: 12-16 ribbons

Shelf Life: Three years

Color: White

Average Character Yield: Approximately 2,000 corrections

Packaging: 6 tapes per box (Minimum order - 1 box)

Reorder Number: 1126455



IBM Film Ribbon Cartridge

Suited for general-purpose typing, offset masters, OCR applications.

Equipment: IBM "Selectric" III and Correcting "Selectric" III Typewriter* equipped with the selective ribbon system.

Average Annual Usage: 10-20 ribbons

Shelf Life: Three years

Colors: Black, Blue Green, Brown

Average Character Yield: 100,000

Packaging: 6 ribbons per box (Minimum order - 2 boxes)

Reorder Numbers:

Black: 1126390

Blue: 1126393

Green: 1126395

Brown: 1126385

* You cannot correct with the correcting key.



Supercor Super Ribbon

For general correspondence typing.

Equipment: IBM "Selectric" II

Typewriter with the fabric ribbon system.

Average Annual Usage: 6 ribbons

Shelf Life: Three years

Color: Black

Packaging: 3 per box (Minimum order

- 1 box)

Reorder Number: Black, 1156139



Typing Elements

The IBM Correcting "Selectric" II and the IBM "Selectric" II Typewriters incorporate interchangeable element technology for the greatest versatility and flexibility in typing. When changing typing applications, simply change the typing element.

Notes:

- Only elements with yellow wiring may be used in this typewriter.
- Using a typing element of one pitch when the typewriter is set for the other pitch will alter only the amount of space between each character.

On top of each element is the following:

- The name of the type style in yellow (example, Courier 90).
- A 10 ▲ or 12 △ indicating pitch.
- The black element release lever (except on elements with a specially requested character which have a white lever).
- A four- or five-digit identification number under the element release lever.

The wide range of type styles available from IBM covers virtually every typing application, from general correspondence to specialized formats. You'll find one right for every typing job. You can even order type elements applicable to specific industries and foreign languages — with special characters, punctuation marks, and symbols. When using elements other than US correspondence elements on a standard 90-character US keyboard, some necessary characters may not print. Under these circumstances you need the 95-character US correspondence keyboard. If you don't find the typing elements just right for you among the standard keyboard arrangements, see "Ordering Procedures."

Ordering Procedures

(U.S.A. Only)

To order IBM supplies, contact your point of purchase.

IBM product center:

_____ (phone number)

Authorized IBM Dealer:

_____ (phone number)

IBM Direct at 1-800-IBM-2466

Element Application Rating¹

Type Style	Original	1-3 Carbon Copies	3-5 Carbon Copies	Offset Masters	Spirit Masters	Stencils
12 ptch						
Advocate	A	A	D	A	B	D
Arboret	A	A	D	A	B	W
Auto Eng	A	A	D	A	A	A
Counter 12	A	A	D	A	B	D
Counter 12 Heavy	A	A	D	A	B	B
Quil Gothic	A	B	C	NR	NR	B
Elite	A	A	A	A	A	A
Large Elite	A	A	B	A	A	B
Letter Gothic	A	A	A	A	A	B
Light Italic	A	A	A	A	A	A
Prestige Plus	A	A	B	A	A	A
Script	A	A	A	A	A	A
Script	A	B	C	A	C	C
Symbol	B	C	C	B	C	C
10 ptch						
Advocate	B	A	A	A	A	A
Bookface Academic	A	B	C	A	B	B
Counter 10	A	A	B	A	B	B
Delegate	A	A	B	A	B	C
Manford	A	A	A	A	B	B
Orator	B	C	NR	C	C	NR
Pica	A	A	A	A	A	A
Prestige Pica	A	B	C	A	B	B
Symbol	A	C	C	B	C	C

¹ Ratings: A - Good; B - Fair; C - Marginal; NR - Not Recommended (based on general experience of ribbon, carbon paper, stencil, and so on).

Application Recommendations for IBM Ribbons

Typing Applications	Tech III	High Yield	Film Ribbon	Fabric
		Correspondence Film	Cartridge	
Legal Correspondence	*	*	-	
Statistical Correspondence	*	*	*	*
Specification Writing	*	*	*	*
Medical Reports	*	*	*	*
Executive Correspondence	*	*	*	
Routine Correspondence	*	*	*	*
Hard-to-Image Originals ¹⁾ Example: Engineering Drawings	*			*
OCR	*		*	
Garbling	*		*	*
Speech Writing ²⁾	*		*	*
Negotiable Instruments — (checks, stocks, etc.)	*		*	*
Creasable Bond ³⁾	*		*	
Reproduction Applications				
Post-Printer	*	*	*	*
Transfer Electronics	*	*	*	*
Direct Electronics	*	*	*	*
Other Masters, Direct to Plate	*	*	*	*
Offset Masters, Copper Process	*	*	*	*
Offset Masters, Photo Process	*	*	*	*
Mask Process, Gray ⁴⁾ or Bruning ⁵⁾	*	*	*	*

When typing Direct Image Other Masters, the IBM Film Ribbon Cartridge or the IBM Tech III Ribbon should be used. When typing negotiable instruments, the IBM Tech III Ribbon should be used.

¹⁾ The receptivity of the surface of these materials varies widely and care must be used in the selection of a specific material to be typed on, type style, impression control, and ribbon to produce the best results. When in doubt, prepare samples first.

²⁾ Best results with Quizer and other large type style elements are obtained by using the IBM Tech III Ribbon.

³⁾ Trademark of the GAF Corporation.

⁴⁾ Trademark of the Chromat Bruning Co., Inc.

Optional Features



Velocity Control Dial

This dial is used when typing with foreign language and technical typing elements.

Hold the dial at the thick line to type small characters such as accent marks.

Move the dial toward the thick line when typing in upper case with elements containing a ten-key numeric cluster, or some foreign language elements with large characters in the keyboard positions normally reserved for punctuation.

For a signpost element, keep the dial at the center position.



Dead Key Disconnect

Standard correspondence elements can also be typed with the use of the dead key disconnect feature.

To allow normal use of a dead key, set the dial at the **OK** position when using a library, language, or bilingual typing element.

Set the dead key disconnect dial at the **→** position for a correspondence element. When the dial is set here, the carrier will space to the next typing position for all characters as they print.

Dead Key

If you regularly use a library, language, or bilingual typing element, your typewriter should be equipped with the dead key feature. With dead key, you can type accent marks without the carrier advancing to the next space.

To use the feature, first type the accent mark; then, type the alphabetic character. The carrier will move after the alphabetic character is typed.

You must space forward before pressing the correcting key when correcting a character on a dead key.



Accoutrements Hood

You can insert paper in the typewriter without lifting the accoutrements hood.

- The view is adjustable to deflect light.

When lifting the cover, pull the accoutrements hood toward you, then lift the cover.

Use a damp cloth and mild soap to clean the hood. Do not use liquid type cleaner.



Legal-Size Single-Page Indicator

Raise the legal-size extension.

Point of Purchase

Company

Representative

Telephone

Ext.

Address

References in this publication to IBM products, programs, or services do not imply that IBM intends to make these available outside the United States.

IBM

International Business Machines Corporation
Information Products Division
For additional information, contact point of purchase.
IPD Form Number G544-0613-2
Printed in USA 5/85
PN 1304900

G544-0613-02

